



Crate King Bed Assembly Instructions

Use for models: 4666,4696,4672,4676,4679,4682,4686 and 4689

Please read the instructions completely prior to starting.

Contents:

- A. Headboard
- B. Footboard
- C. 8 – 4” Lag bolts
- D. 2 – Side rails
- E. 8 – Washers
- F. 4 – Slats
- G. 4 – 1 ½” Wood screws
- H. 4 – 1 ¼” Wood screws
- I. Centre rail

Tools required:

- $\frac{9}{16}$ ” Socket or wrench
- #2 Robertson or Phillips screwdriver

1. The sides of the bed ends with the “Brackets” are the insides. Fasten the 2 side rails “D” to the 2 bed ends “A” & “B” using 8 – 4” lag bolts “C” with the 8 washers “E”. Be sure grooves on side rails are on the inside, close to the bottom. Do not fully tighten bolts.
2. Slide centre rail “I” into the brackets on the headboard & footboard & finish tightening the bolts.
3. Slide 4 slats “F” into the side rails. 2 slats are placed $\frac{1}{2}$ ” from the bed ends & secured with a wood screw “H” at each end of the slat. The remaining slats should be centred between the two end slats and secured with a wood screw “G” at each end of the slat.
4. Add optional posture board or foundation & mattress.
5. If a drawer unit is to be added to this assembly it simply slides under the bed and does not attach to the bed.
6. If a trundle bed is to be added to this assembly the centre rail brackets must be moved off-centre to accommodate it.

